

TABLE OF CONTENTS

INTRODUCTION

What Is The Student Guide?
How To Use The Student Guide
Additional Books REQUIRED For Westlawn Study
Reference Papers & Reference Material
Reference Drawings
Career Advice
Requirements For Submitting Lessons
Submitting Original Drawings Thru The Mail
Receiving Lesson Reports Via Email
Neatness Counts
Using Spreadsheets

1 – MATH, HYDROSTATICS, WEIGHT CALCULATIONS

1.1 - Mathematical Equation Procedures & Rounding Large Numbers

Proper Math Equation Procedure
Rounding Large Numbers
Greek Letters Used In Formulas/Equations
Do Not Use Commas As Decimal Points

1.2 - Hydrostatics, Planimeter Use and Readings, Required Hydrostatic Data

Hydrostatic Calculations, Planimeter Readings, and Section Half-Area
Planimeter Scale Factor and Planimeter Use
Hydrostatic Data Sheet REQUIRED With Every Design – USE AS CHECKLIST
Additional Data-Sheet Information REQUIRED – USE AS CHECKLIST
Hydrostatics And Baselines Or Reference Lines

1.3 - VCB, Trapezoidal Rule, Estimating the VCG & Calculating Hull Shell CG

VCB Vertical Center of Gravity Calculations for Hydrostatics - “Morrish” VCB Method
Trapezoidal Rule Instead of Simpson’s Rule
Preliminary Estimation of Center Of Gravity
Vertical Center of Gravity and Stability Calculations
Calculating Hull-Shell Center of Gravity

1.4 - Finding Volumes – The Prismoidal Formula

1.5 - Weight And Trim Calculations

An Example Weight Calculation
Weight-Calculation Margins And Allowances
Combining LCB, LCF, MTI, And PPI To Find Combined Flotation And Trim
Indicate Location of LCB and LCG Clearly On Weight Calculations
Transverse Center Of Gravity Calculations

1.6 - Preliminary Stability Estimates, Estimating GZ And GM At Various Heel Angles

1.7 - Evaluating And Thinking About Speed – Speed-Length Ratio and Froude Number

Speed-Length Ratio (SL ratio)
Froude Number (Linear – “Fnl”)
Froude Number (Volume or Cubic – “Fnv”)

1.8 - Units Of Pressure, Stress And Force For Metric Structural Calculations

2 – DRAFTING—MANUAL & CAD

2.1 - Drafting, Manual & CAD - Introduction

2.2 - Drafting—Manual Drawing & Lineweights In CAD And Manual Drawing

- Don't Mix CAD And Hand Drawing – Use Proper Vellum And Mylar**
- Lineweights And Lead Hardnesses**
- Hide Hidden Lines**
- The Drawing-Board Surface**
- Marine Manual-Drafting Techniques**
- Details In Drawings**
- Practical Marine Drafting**
- Drawing Conventions**
- Hull Lines Drawings**
- The Midships Symbol And “FP” AND “AP”**
- Table of Offsets**
- “Blueprints” vs Giant Xerox**
- About Inking**
- Drawing Size**
- Folding Drawings**
- Title Blocks**
- Drawing Scales And Drawing-Scale Labeling**
- Dimensioning and Dimensioning Systems**
- Gridlines On All Drawings**
- Shading And Hatching On Drawings**
- Lettering Size And Lettering Quality**
- Notes On Number Of Section Drawings Required (Module 3)**
- Fore-n-Aft Frame Reference Locations (Module 3)**
- The Importance Of Quality Drafting**

2.3 - Submitting Drawings Electronically & Maximum CAD Drawing Size

2.4 – CAD, Computer Systems & Software:

- Recommendations Regarding CAD**
- How To Order Academic-Discount Software**
- Some Common High-End CAD Programs**
- Suggestions On Computer Systems**

2.5 - Drafting – CAD Drawing:

- Details In Drawings**
- Gridlines - Additional Information**
- Shading And Hatching - Additional Information**
- Units In AutoCad**
- Making Proper Use of Model Space**
- Using Paper Space**
- 3D Drawings/Modeling In CAD**
- Color In CAD Drawings**
- Color and Lineweights In AutoCad**
- CAD Plot File Formats**
- PDF Check Plots**
- AutoCad “Express Tools”**
- 3D Modeling And 2D Working Drawings**
- Standard Steps for Doing a Boat Design in CAD**

2.6 - Developable Surfaces

- Developable Surfaces or Hulls of Conic Sections**

3 – GENERAL DESIGN

3.1 - Laying Out a Workable Arrangement

- Seats and Tables**
- Helm Seats**
- Toilets/Heads, Showers**
- Berths**
- Counters and Cabinets**
- Headroom, Doors, Passageways, and Hatches**
- Stairs**
- Side Decks**
- Lifelines And Stanchions**
- Sight lines From The Helm**
- Avoid Excessive Open Spaces**
- Avoid Movable Furniture**
- Draw In The Cabin Sole**
- Using People Blocks in CAD**

3.2 - Common Mistakes

- Don't Forget Limber Holes**
- No Sharp Outside Corners**
- Engine: Clearance, Sound Insulation, Ventilation, Access, Removal, Exhaust**
- Engines Are Not Mirror Image**
- Don't Run Insulation Down Into The Bilge**
- Masts Should Not Penetrate The Trunk Cabin In line With A Window**
- Show Masts In The Inboard Profile And Arrangement Plans**
- Don't Put Opening Windows In The Topsides Of Sailboats**
- Don't Locate Tanks Near The Ends Of The Boat**
- Don't Install Tanks That Run Athwartships**
- Rudder Center Of Pressure Is At 35% Of Mean Cord**

3.3 - Design For Production

- Repeatability**
- Minimizing Liability**
- Minimizing Waste**
- Reducing Labor Time**
- Optimizing For Transport And Delivery**

4 – SAILBOAT DESIGN

4.1 - Factors Governing Sailboat Performance

- Sailboat Performance—Design & Form**
- Practical Design Guidelines For Sailboats**
- Evaluating Sail-Carrying Power – Dellenbaugh Angle and Wind Pressure Coefficient**
- Righting Moment On Small Sailboats**
- Extreme Performance Monohulls**
- Twin Rudders On Sailboats**
- Sailboat Examples In Westlawn Texts**

4.2 - Saildrive Installations

4.3 - Mast and Rig Design

- Rigging Loads Must Be Balanced**
- Desirable Mast Bend**
- Shroud Tang Location**
- Shroud Layout In Profile View**

Continuous and Discontinuous Rigging
Modern Standing Rigging—Wire, Rod, High-Modulus Fiber
316 Alloy 1x19 Wire Rigging Size And Strength Table
Laying Out Shrouds And Chainplate Locations
Dimensioning Headsails For Proper Sheet Lead
Swept-Back Spreader Detailing
Calculating Shroud Loads And Mast Compression With Swept-Back
Spreaders And Proper Sweep-Back Angle
Avoid Drooping Booms & Boom Clearance
Boom Section Size
Running Rigging Sizes

4.4 - Chainplate Design

Standard Flat-Bar Chainplates
Chainplate Attachment and Design Load
Stress And Bearing Area For Chainplate Bolt Holes
Chainplate Bolt Diameter And Number Of Bolts In Plywood
Reducing The Number Of Chainplate Bolts With Annuluses
Minimum Chainplate-Bolt Spacing
Chainplate Bolt Diameter And Number Of Bolts In Fiberglass
Thickness Ratio
Chainplate-Bolt Shear Area Requirements
Chainplate Bolts In Cored Bulkheads
Fastening Chainplate Knees To The Hull – Secondary Fiberglass Bond Stress In Shear
Chainplates Fastened To Tie Rods – Secondary FRP Bond Stress In Tension
Reinforcing The Hull Structure At The Mast And Chainplates

4.5 - Unstayed Mast Design

Unstayed Masts – Overview
Unstayed Masts Are Cantilever Beams
Calculating Loads On An Unstayed Mast
Determining The Size Of An Aluminum Unstayed Mast
Determining The Size Of A Carbon-Fiber Unstayed Mast
Limitations Of Unstayed Masts
“Unstayed” Masts With Headstays
Spar Taper On Unstayed Masts
Standard Spar Taper
Calculating Deflection In Unstayed Masts

4.6 - Keel Design

The Multiple Functions Of Keels
Brute Force vs Finesse
Traditional Long Full Keels
Theory Of Modern Fin Keels
Fin-Keel Planform
Aspect Ratio
Lift-To-Drag Ratio
The Standard Trapezoidal Keel
Fin-Keel Geometry Definition
Fin-Keel Area Relative To Sail Area And Aspect Ratio
Proportioning The Optimum Trapezoidal Planform For Best Lift-To-Drag
Example Keel Drawings
The 67% Root-Cord Compromise Keel
Use Of The Optimal Planform Keel
Keel Section Or Foil Shape
Foil Geometry And Nomenclature

Selecting A Standard Foil Section
Foil Sections Change With Height On The Keel
Keel-Bottom Shape
Bulb Fin Keels
Bulb Forms With Less Induced Drag
Other Fin-Keel Forms
Extreme Keels – Forward-Projecting Bubs, Wing Keels & Winglets
The Scheel Keel
Centerboard And Keel-Centerboarders
Keel Ballast Attachment

5 - MULTIHULL DESIGN

5.1 - Notes On Catamaran Design

5.2 - Trimaran Hull Proportions

5.3 - Multihull Hydrostatics

5.4 - Catamaran Nomenclature

5.5 - Trimaran Nomenclature

5.6 - Ama (Outer Hull) Buoyancy and Stability, and Flying a Hull

5.7 - Ama (Outer Hull) LCB

5.8 - Multihull Crossbeams

5.9 - Multihull Crossbeam Loads

5.10 - Sailing Multihull Stability and Performance Indicators:
Bruce Number, RPI, Stability Number & Stability Factor

5.11 - Multihull Sailplan Lead

5.12 - Notes On Multihull Rigs & Righting Moment

5.13 - Don't Use Long Keels On Multihulls

5.14 - Visibility From The Helm On Catamarans

6 – POWERBOAT DESIGN

6.1 - Length-To-Beam Ratio

6.2 - Chines

6.3 - Deadrise

6.4 - Section Shape, Chine Shape In Body Plan

6.5 - Buttock Angle And Shape And Planing Angle

6.6 - Hook, Wedges, Shingles, Trim Tabs And Planing Trim Angle

6.7 - Spray Knockers Or Chine Flats – More On Chine Proportions And Location

6.8 - Example Lines Of Good Planing Hulls

6.9 – Spray-Rail Location And Proportions

6.10 - Location Of LCG And LCB

6.11 - Displacement-Length Ratios

6.12 - Prismatic Coefficients

6.13 - Tumblehome In Planing Hulls

6.14 - Avoid Hollow Waterlines Forward

6.15 - Planing-Hull Examples In The Westlawn Texts

6.16 - Estimating Range And Fuel Tankage

7 - CONSTRUCTION

7.1 – Aluminum Construction

Think Aluminum

Avoid Sharp Corners In Metal Construction

Floating Frame vs Standard Frame in Metal Construction

Metal Boat “Egg-Crate” Framing Details And “Intercostal” Framing

Bulkhead and Frame Locations and Installation in Metal Boats

Longitudinal Layout

7.2 - Laminate Schedules And FRP Construction Details

Glass Content By Weight

7.3 - Guidance On Internal Framing For Fiberglass Hulls

7.4 - Hydrostatic Head Height For Displacement-Boat Structural Calculations

7.5 - Advanced-Composite FRP Construction and Composite Fin Keels

Notes On Advanced-Composite Fiberglass Construction

Carbon-Fiber Laminates

Deep Composite Fin Keels With Ballast Bulbs

7.6 - Notes On Wood Construction

Lumber Size Specifications

Use Scantlings From *The Elements of Boat Strength*

8 - SYSTEMS, EQUIPMENT, AND SPECIFICATIONS

8.1 - Halon Discontinued for Fire Extinguishers

8.2 - Electric Systems

DC Ground Wiring And DC Wiring In General

12-Volt DC vs 24-Volt DC

Bonding (Grounding) And Negative (Grounded) Conductors

Separate Drawings For DC And AC Systems

AC Wiring (Including Isolation Transformers And Selector Switches)
Electric Wiring Color Code (US Practice)
Alternators, Battery Charging, And Battery Banks
Inverters And Battery Chargers (Converters)
Separate AC And DC Wiring Onboard
Circuit-Panel Basics
Electric-System References

8.3 - Electric Component Sizing Guidelines

Estimating Battery-Bank Capacity
Battery Considerations
The Proper Alternator
Shoreside Chargers
AC from DC — Selecting an Inverter
Sizing an Electric System
House-Bank Battery Consumption and Charging Time
Inverter Current Draw

8.4 – Sizing Mooring And Docking Cleats And Chocks

8.5 - Specifications

9 – PUTTING IT ALL TOGETHER—THE PRELIMINARY DESIGN

9.1 - Starting Your Preliminary Design Work

9.2 - Defining The Midships Section

9.3 - Estimating Power And Range

9.4 - Laying Out A Preliminary Sailplan

9.5 - Checking Sail-Carrying Power And Stability

Estimating Waterplane Moment Of Inertia And GM

Estimating GZ From Estimated GM

Estimating Sail Carrying Power—Dellenbaugh Angle And WPC

9.6 - Drawing The Preliminary Lines

9.7 - Improving And Correcting Your Preliminary Sketches

9.8 - Checking Weights, LCG, VCG, And Lead

9.9 - Preliminary Drawings As Opposed To Preliminary Sketches

APPENDIX A – Example Weight-and-Trim Calculation

APPENDIX B – Example Laminate Schedule And Construction Details

APPENDIX C – Modern FRP Laminate Mechanical Properties Tables

APPENDIX D – Example Preliminary Sketches And Drawings

APPENDIX E – Example Title Blocks